

# Übermilk cleaning instructions



**ATTENTION!**  
Use cleaning agents exclusively for this device.

## 1. Preparation



1. Materials required: **2 containers** (min. 2 liters), **Übermilk cleaner**. There are **two different cleaners**: Whether to use cleaner 1 or 2 is shown in the display.



2. Go to „Settings“. Press the „Cleaning“ key. Follow the instructions on the display. Place an **empty collection container** under the outlet.

## 2. Pre-rinse



1. Remove the outlet head and **dispose of the filter disc**. A new **filter disc** is inserted **daily at the start of operation**.



2. Pour **clear, warm water** into the cleaning container. Remove the **milk hose** from the milk container and place it in the **cleaning container with water**. Carry out the first cleaning step according to the instructions in the display!

## 3. Main cleaning



1. Empty both containers. Place the collection container under the outlet. Pour **50ml Übermilk cleaner** and **1.5l water** into the cleaning container. The **cleaning agent to be used (1 or 2)** is shown in the display.



2. Place the **intake hose** and **all parts of the outlet head** in the **cleaning container**. Start the next cleaning step! (Remaining time is shown on the display).

## 4. Rinse out



1. Empty both containers and **rinse the cleaning container very thoroughly**.



2. Fill the cleaning container with **2 liters of clear, warm water**. Perform the final step to **rinse the Übermilk**.

## 5. Final step



1. Empty both containers and **rinse them out**. **Clean the intake hose, the thread of the outlet and the Übermilk case** with a damp cloth.

2. Switch off the Übermilk at the **toggle switch**. The device is now ready for the next day of operation.

## Safety instructions



- Wash and disinfect hands before and after cleaning.
- Wear **gloves & safety goggles**.

## Employee confirmation

I have taken note that:

- I may only clean Übermilk with the appropriate cleaning agents.
- I must wear protective gloves or protective clothing during cleaning.
- I must wear safety goggles during cleaning.
- I have fully understood the cleaning steps.

\_\_\_\_\_

Date / Signature of employee